

# EURO 46 V10

## Installation Manual

PD6662:2010+IA501:2015  
EN50131-1:2008+A1:2009  
EN50131-3:2009  
Security Grade (SG) 3 - Large  
Security Grade (SG) 2 - Small  
Environmental Class (EC) II





# Contents

<b>System Overview</b>	<b>4</b>
Default Codes	4
Input Mapping	5
Output Mapping	6
Regulatory Wiring Requirements	6
Technical Specification	7
<b>Out of the Box</b>	<b>9</b>
<b>The Printed Circuit Board</b>	<b>10</b>
Communication Loom	11
<b>Power and Battery Connections</b>	<b>12</b>
<b>485 Bus Wiring</b>	<b>13</b>
Star and Daisy Chain Wiring	14
<b>Input Connections</b>	<b>15</b>
<b>Output (PGM) Connections</b>	<b>16</b>
Relay and Speaker Output	16
XPGM Outputs	16
<b>External Sounder Connections</b>	<b>17</b>
Grade 3 Wiring	17
Grade 2 Wiring	17
<b>Modems</b>	<b>18</b>
<b>UDL Software</b>	<b>18</b>
Connecting RS232 to the Panel	18
Connecting InSite to the Panel via RS232	19
Setting up a Cloud Connection	19
Connecting InSite to the Panel via the Cloud	20
<b>EN 50131 Terminology</b>	<b>20</b>
<b>Access Levels</b>	<b>21</b>
<b>Compliance</b>	<b>21</b>
<b>Warranty</b>	<b>21</b>
<b>Additional Device Manuals</b>	<b>22</b>
Wired Setting Devices	22
Wireless Setting Devices	22
Zone Expansion Modules	22
Output Expansion Modules	22
External Wired Sounders	22
<b>Customer Support</b>	<b>23</b>
Pyronix Training Academy Online	23
Pyronix Training Academy Training Videos	23
Technical Support	23

# System Overview

System Overview		EURO 46 V10	Additional Information	
Areas				
Independent areas		6		
Wards		5	Each ward is created by a proximity reader	
Inputs				
On board		8	Supports N/C, 3EOL, DEOL and SEOL	
Wireless		64	Requires 2 x EURO-ZEM32-WE	
Maximum		76	Refer to 'Input Mapping' table	
Outputs				
PCB		5	1 Relay, 4 transistor (inputs 7 & 8 may be used as outputs)	
ATE		10	Low power ATE outputs	
Maximum		85	Refer to 'Output Mapping' table	
User automation		30	Outputs programmed to activate on user command	
Users				
Users		75		
Wireless key fobs		32	Requires 1 x EURO-ZEM32-WE	
Guard/duress		10		
Engineer		1		
Maximum		87	Including Master Code and wireless key fobs	
Arming Devices				
Wired		6	Keypads and proximity readers	
Wireless		4	Requires 1 x EURO-ZEM32-WE	
Communication				
Compatible modems		PSTN, PSTN/VOICE, GSM, GPRS, Wi-Fi/XA and LAN		
ARC formats		Contact ID, Fast Format and SIA3 (also IP variants in all 3)		
User formats		Push notifications, SMS messaging and Voice messaging.		
Phone numbers		10	Used for SMS messaging	
UDL Support		Yes	Using the upload/download software	
Logs				
Memory		1250	Memory type is EEPROM	
Dimensions and Compliance				
Dimensions (H x W x D)	Small Case	297 x 250 x 82 mm	PCB	110 x 170 x 40 mm
	Large Case	390 x 305 x 100 mm		
EN grading		2 (small metal) 3 (large metal)		
Environmental class		II		

## Default Codes

Engineer - 1111

Master Manager - 2222

## Input Mapping

Devices	Address	Input Numbers
EURO 46 V10 PCB	N/A	1-8
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	0	9-16
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	1	17-24
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	2	25-32
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	3	33-40
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	4	41-48
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	5	49-56
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	6	57-64
EURO-ZEM8 / EURO-ZEM8+ / EURO-ZEM8+PSU / EURO-ZEM32-WE	7	65-72
EURO-LCD/EX	0	73-74
EURO-LCD/EX / EURO-PROX/INT	1	75-76
TOTAL		76

**PLEASE NOTE:** 2 x EURO-ZEM32-WE can be connected to the EURO 46 V10. Each expander allows 32 inputs which are separated into 4 addresses (each address enables 8 wireless inputs). It is possible to mix the wired and wireless remote expanders.

**PLEASE NOTE:** If the EURO-PROX/INT (Internal Tag Reader) is programmed as a 'Set Point' device, 2 inputs are enabled. If the EURO-PROX/INT is programmed as 'Entry Control' or 'Access Control' only 1 input is enabled.

## Output Mapping

Devices	Address	Outputs Numbers
EURO 46 V10 APP PCB	N/A	5 (2 shared)
Digi/ATE Outputs (using communication loom)	N/A	10
EURO-OEM8R8T / EURO-OEM16R+PSU	0	1-16
EURO-OEM8R8T / EURO-OEM16R+PSU	1	17-32
EURO-ZEM8+ / EURO-ZEM8+PSU	0	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	1	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	2	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	3	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	4	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	5	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	6	1-4
EURO-ZEM8+ / EURO-ZEM8+PSU	7	1-4
EURO-LCD/EX	0	1
EURO-LCD/EX / EURO-PROX/INT / EURO-EXT-BK/W	1	1
EURO-LCD/EX / EURO-PROX/INT / EURO-EXT-BK/W	2	1
EURO-LCD/EX / EURO-PROX/INT / EURO-EXT-BK/W	3	1
EURO-LCD/EX / EURO-PROX/INT / EURO-EXT-BK/W	4	1
EURO-LCD/EX / EURO-PROX/INT / EURO-EXT-BK/W	5	1
Total		85

## Regulatory Wiring Requirements

- Ensure wiring is done to the national wiring regulations in the country where the installation is taking place. In the UK, this is BS 7671 Requirements for electrical installations; IET Wiring Regulations (17th edition). If in doubt, consult a local qualified electrician.
- Ensure that a readily accessible disconnect device incorporated in the premises installation wiring shall be provided external to the equipment with a contact separation of at least 3,0mm and connected as closely as possible to the supply. Example: Fused Spur Unit
- When fixing external wires, ensure that means are provided in the installation to prevent the SELV (Safety Electrical Low Voltage) or signal circuits from coming into contact with live parts of the power supply circuit. Wires shall be fixed near their terminal blocks.
- The end of stranded conductor shall not be consolidated by soft soldering at places where the conductor is subjected to contact pressure. Example: Must not solder ends of wires which are to be secured in detector and control panel terminal connectors.
- On completion of wiring use tie-wraps to prevent any loose wires causing a safety hazard (material of cables tie shall be rated at least HB or better).
- Cables ties and sleeves shall be separate for power supply cable and SELV (Safety Electrical Low Voltage) wirings.
- Size of protective bonding conductors: minimum section 1.5mm<sup>2</sup>. Example: Electrical Earth wire connections.

# Technical Specification

Programming Outputs		Power Rating	Normal State	Active State
PGM 1		Relay, 3A, max 30V	Changeover NC & NO	Changeover NC & NO
Speaker		16 ohms	No tones	Repeat RKP tones & internal sounder
Strobe output		500mA	12v	0v
Bell output		500mA	12v	0v
XPGM 1 (Input 7)		50mA	Floating	0v
XPGM 2 (Input 8)		50mA	Floating	0v
ATE outputs		2mA	5v	0v
Circuit States		Resistance Range		
		1k / 1k Range	4k7 / 2k2 Range	4k7 / 4k7 Range
Normal		0k5 to 1k4	1k4 to 2k9	3k7 to 8k3
Alarm		1k5 to 5k9	4k2 to 7k8	8k4 to 10k2
Fault		6k to 8k1	8k to 11k3	10k3 to 14k9
Masking		8k2 to 17k	11k6 to 22k	15k to 22k
Tamper		<0k5 or >17k	<1k4 or >22k	<3k7 or >22k
Fuses			Value	Type
Bell fuse for bell terminals			F800mA quick blow 250V	Glass
Aux fuse for aux terminals			F800mA quick blow 250V	Glass
RS485 bus fuse for bus terminals			F800mA quick blow 250V	Glass
Battery fuse for battery terminals			T 1.5A anti-surge slow blow 250V	Glass
230V mains fuse for mains terminals			T500mA H anti-surge slow blow 250V	Ceramic
Panel Power Supply Output			Nominal	Range
Output voltage			~13.7VDC	~10-15VDC
Output current	Small Metal		1A Continuous	1.5A peak, during battery charging
	Large Metal		1.5A Continuous	2.0A peak, during battery charging
Panel Power Supply Input			Nominal	Range
Mains supply voltage AC			230 VAC at 50Hz	-15% +10 %
Transformer rating	Small metal		18VA	18V at 1.0A
	Large metal		45VA	18.5V at 2.5A
Power Supply Type A.				
Maximum output peak voltage: Max 100 mV				
SD Voltage which the deep discharge protection function will operate at: 10V				
Over Voltage Protection Trigger Voltage: 18V				
Battery Charging Specification				
Float voltage	13.8VDC	Recharge time	<24 hours	
Battery low voltage cut off	10.5V	Standby battery capacity current	300mA (3A to 6A)	
			700mA (7A to 17A)	

**PLEASE NOTE:** EURO 46 V10 power supplies are NOT designed for use with multiple batteries connected. System load should not exceed the panel power supply output shown above, or the maximum load supportable by the battery for the specified backup time, as in the table shown below. The power ratings are based on battery shown in table – but battery capable of supporting the system load for the required time may be used without affecting these ratings.

EN50131-6:2008 Rated Output			
In accordance with EN50131-6:2008, the EURO standby times and effective output currents depend on the Security Grade of the system and how 230V mains missing fault is signalled to the Alarm Receiving Centre. Power supplies are rated in accordance with the requirements of EN50131-6, which are related to the maximum battery size that can be accommodated in the housing and vary according to the grade of the system in which they are installed, as per the following table:			
Electrical Capability		EN50131-6 Rating. Maximum Load	
Example Battery Model		Grade 2	Grade 3
Yuasa NP7-12		0.5A	0.3A
Yuasa NP17-12		1.2A	0.7A
EURO 46 V10 PCB Current Consumption		Environmental	
Quiescent	80mA	Operational	-10°C to +40°C, Certified
User Code and Tag Guessing		Storage	-20°C to +60°C
4-digit codes	10,000	Humidity	75%
6-digit codes	100,000	Dimensions	
Disallowed codes	None	Metal case	Small case 250 x 297 x 82mm Weight: 4.8kg inc. battery
All codes	16 <sup>12</sup>		Large case 390 x 305 x 100mm Weight: 11.5kg inc. battery
According to EN50131-3:2009 Annex B		PCB	170 x 90 x 30mm
According to spec of manufacturer of RFID components used		EN50131 Grading	3

The below table specifies ATS (Alarm Transmission System) performance criteria in accordance with the requirements of EN50136-1.

Notification Equipment	Grade 2 Criteria				Grade 3 Criteria			
	Options				Options			
	A	B	C	D	A	B	C	D
Remotely powered external sounder	2	Optional	Optional	Optional	2	Optional	Optional	Optional
Self-powered external sounder	Optional	1	Optional	Optional	Optional	1	Optional	Optional
Main communication path (ATS)	ATS 2	ATS 2	ATS 2	ATS 3	ATS 4	ATS 4	ATS 4	ATS 5
Second communication path (ATS)	Optional	Optional	ATS 1	Optional	Optional	Optional	ATS 3	Optional



## Out of the Box

Unscrew and remove the cover of the EURO 46 V10 (Figure 1). The EURO 46 V10 printed circuit board is located to the top right hand side. (Figure 2)

Install the supplied stand-offs if needed before mounting the metal case to the wall (Figure 3).

Connect any modems if required and any other devices (input expanders, output expanders etc.) before powering up the system.

Screw the back metal plate to the wall.

Wire the telephone line if the DIGI-1200 modem (PSTN) is installed or the LAN cable if the DIGI-LAN is installed.

Install the SIM card, connect the antenna and locate outside of the metal casing if the GPRS or Wi-Fi modem is used.

EURO 46 V10: The tamper mechanism comes already fitted.




Figure 1




Figure 2








Figure 3


Secure all the wires and close the enclosure making sure the tamper is operational.

Turn on the power to the EURO 46 V10.

On power up, the panel will typically show the below screens.



# The Printed Circuit Board



**1: Case tamper 'Hold-Off' jumper**

**2: PGM 1**

**3: Speaker connection**

Connects a 16ohm speaker.

**4: External sounder connections**

Connects an external sounder.

**5: Input connections**

8 Fully programmable inputs.

**6: Tamper switch**

Optional tamper protection for the metal casing.

**7: Auxiliary 12V power**

12V power supply

**8: Inputs or outputs**

Inputs 7 and 8 may be programmed as outputs if unused.

**9: Battery connect 'Kick-start' switch**

To power-up and program from battery power (when there is no mains power available).

**10: RS485 bus terminals**

Connects peripherals.

**11: Battery connection**

For battery back up.

**12: Earth connection**

Connects the earth.

**13: 17V connection**

Connects the AC transformer 17V supply.

**14: Battery charge capacity jumper**

For battery back up.

**15: Modem connections**

The left connector (labelled 'modem') is for signalling modems.

**PLEASE NOTE:** The right is 'For Future Use', please do not use.

**16: RS232 Connection**

This connection is used for an RS232 lead that will connect to a PC to allow uploading and downloading of data using the InSite software.

**17: Communication Outputs**

Connects the supplied communication loom to enable an additional 9 programmable outputs.

These are low current and would normally be used when connecting a stand-alone communicator to the panel.


**18: Bell Fuse**

**19: Auxiliary Fuse**

**20: Bus Fuse**

**21: Battery Fuse**

## Communication Loom



The ATE (Alarm Transmission Equipment) outputs are programmed in the Engineer Menu. The programming can be found in 'CHANGE OUTPUTS' then sub menu 'Endstation Outputs'.


Normal Status: 5v

Active Status: 0v

Current: 2mA

**PLEASE NOTE:** The polarity of the ATE outputs can be changed in the Engineer Menu. The menu option is named 'Invert ATE O/Ps' and can be found as a sub menu in 'SYSTEM OPTIONS' then 'Site Options'. This will invert the polarity of all the programmable ATE outputs, they cannot be done individually.


# Power and Battery Connections



Panel Power Supply Input		Nominal	Range
Mains Supply Voltage AC		230V AC at 50Hz	-15% +10%
Transformer Rating		18VA	18V at 1.0A
Panel Power Supply Output		Nominal	Range
Output Voltage		13.7V DC	10-15V DC
Output Current	Small Metal	1A Continuous	1.5A peak, during battery charging
	Large Metal	1.5A Continuous	2.0A peak, during battery charging
Power Supply Type A.			
Battery Charging Specification			
Float Voltage	13.8v DC	Control Panel Type	
Battery low voltage cut off	10.5v		Standby battery capacity current
Recharge time	<24 Hours		700mA (7Ah to 17Ah)
Fuses		Value	Type
230V Mains Fuse for mains terminals		T500mA H anti-surge slow blow 250V	Ceramic

**PLEASE NOTE:** Ensure that the 'battery jumper' is in the correct position for the capacity of battery that you have connected – otherwise the panel may under-charge a large battery or over-charge and damage a smaller battery.

# 485 Bus Wiring



All 485 bus peripherals; LCD keypads, readers, expanders etc. are connected via the D1-, D2+, D3 and D4 terminals. This is an example of what a typical 485 bus may look like.

## General Principles:

**NOTE 1:** No alarm system cable should be run with other cables carrying AC or digital signals.

**NOTE 2:** The cables should be protected by the use of grommets where appropriate.

**NOTE 3:** For greater than 1000m range a standard isolated RS485 repeaters required.


**NOTE 4:** There must be a ferrite bead fitted to one of the outgoing data lines and secured inside the EURO 46 V10 case itself. The Ferrite bead is supplied packaged with a cable-tie which must be used to secure it in the case and prevent it shorting any electrical contacts (Ferrite as shown).

There must also be a ferrite bead fitted to the data wires of a EURO-PROXE (if connected). The Ferrite bead is supplied with the reader.


**NOTE 5:** If an expansion module with a power supply on board is connected, the D2+ terminal must not be connected between the main bus and module.

## Star and Daisy Chain Wiring

Star Wiring Example



Daisy Chain Wiring Example




Cable Type	Screened Cable	Bus Range (m)	Wiring Format	
			Star Wiring Range	Daisy Chain Range
4 core alarm cable	Use this type of cable when the wiring of the 485 bus is located near 230VAC mains power wiring	300	50 m	1 km
6 core alarm cable (doubling D1 (0v) and D2 (+12V))		1000		
Twisted Pair		1000		

# Input Connections

The EURO 46 V10 has options of 4k7/2k2, 4k7/4k7, 1k/1k and wide EOL ranges to choose from. The tolerances for each of these ranges can be found in the technical specification. The 'wide' range has no masking tolerance range. This is added on to the end of the alarm tolerance in order to create a wider alarm tolerance range.

EURO 46 V10 panels are set to 4k7/2k2 at default and would typically used a 2k2 resistor for tamper, 4k7 resistor for alarm and finally a 6k8 resistor for mask.



**PLEASE NOTE:** If 'Normally Closed' (double pole) wiring is utilised, The EOL range must be set to '4k7/2k2' and the EOL mode set to 'DR'. This can be selected in the Engineer Menu in the menu 'CHOOSE MODE'. The 'Diagnostics' on the keypad will show 6K9 when the alarm circuit is open and 2K2 when the alarm circuit is closed. It will show >22k when the tamper circuit is open.




For specific wiring instructions please refer to the installation manual provided with each component that is being wired to the system.

# Output (PGM) Connections


## Relay and Speaker Output

Normal State: Floating  
Active State: 0V  
Current: 100mA



## XPGM Outputs

If Inputs 7 and 8 are programmed as 'unused', these inputs can be used as 2 further outputs (known as XPGM1 and XPGM2). Which are programmed in 'CHANGE OUTPUTS' in the Engineer Menu.




Normal State: 12V  
Active State: 0V  
Current: 50mA switched to 0V




# External Sounder Connections

## Grade 3 Wiring



## Grade 2 Wiring



## Modems

There are 6 modems there are compatible with the EURO 46 V10 panel. These are:

- DIGI WIFI/XA
- DIGI LAN
- DIGI GPRS
- DIGI GSM
- DIGI 1200
- DIGI PSTN/VOICE


For installation instructions please refer to the manual provided with the modem.

For programming instructions please refer to the 'Communications Guide'.

## UDL Software

The EURO 46 V10 control panel can be programmed by the LCD menu or the UDL InSite Software, provided free of charge. It can be downloaded from <https://www.pyronix.co.uk/help-and-support/installers-distributors/insite-software-download/insite-software-download>. The connection between control panel and UDL software can be done in the following ways:

### Connecting RS232 to the Panel



Enter the Engineer Menu.

Scroll the menu (**NO** button) until the 'SET UP DOWNLOADING?' and press **YES**.

Choose RS-232 in the "Download by" option – Press **YES**.

Now on the 'UDL Password' screen, leave 'blank' and Press **YES**.

Now on the 'Site Name' screen, this is compulsory, make sure that you take a note of it for use later in the InSite software then press **YES**.

Now on the 'UDL Priority' screen – we recommend setting this to 'High [0]'.

**PLEASE NOTE:** This prevents HomeContol+ App events / notifications from disconnecting the UDL connection.

## Connecting InSite to the Panel via RS232

To setup the COM port associated to 'modem', open the software, click on 'Configuration', choose "Modem Settings" and select "RS-232" option.

Make sure that the serial COM port used by UDL is the set the same in the PC.

**PLEASE NOTE:** This can be found in the PC via Control Panel > Device Manager > Ports.

Make sure that in the UDL Graphic user interface, the RS-232 icon is green.

Click on 'Roving Dial Customer'.

Set 'Dial Mode' field to 'RS-232'.

Enter the Engineer Code in the 'Engineer Code' field.

Click on 'Dial'.

If connection is successful, the RS-232 icon will become blue.

## Setting up a Cloud Connection

Enter the Engineer Menu.

Scroll the menu (**NO** button) until the 'SET UP DOWNLOADING?' and press **YES**.

Choose 'Cloud' in the 'Download by' option – Press **YES**.

Make a note of your 'System ID' (to enter in the InSite software later) - Press **YES**.

Select Security level – for initial connections we recommend [0] (normal) - Press **YES**.

Create/enter a system password and take note of it - Press **YES**.

Now on the 'Poll Server' screen – select 'Yes [1]' and press **YES**.

Now on the 'UDL Password' screen – DO NOT USE – leave blank and Press **YES**.

Now on the 'Site Name' screen, this is compulsory, make sure that you take a note of it for use later in the Insite software then press **YES**.

Now on the 'UDL Priority' screen – we recommend setting this to 'High [0]'.

**PLEASE NOTE:** This prevents HomeControl+ App events / notifications from disconnecting the UDL connection.

## Connecting InSite to the Panel via the Cloud

Click on 'Roving Dial Customer'.

Click on the 'Dial Out Mode' drop down list and select 'Cloud'.

Enter the 'System ID' of your panel (see 'SET UP DOWNLOADING?' in the panel Engineer Menu).

Enter 'System Password' (see 'SET UP DOWNLOADING?' in the panel Engineer Menu).

Leave the UDL security at 'normal' for initial connection test in 'System Security Level' field.

Enter the Engineer Code as used on the panel you are trying to connect to.

Enter 'Site Name' as entered in panel.

Enter an appropriate panel name into the 'Enter Customer In Database As' field.

**PLEASE NOTE:** This is just for identification in the InSite software, nothing more.

Click 'Dial'. If connection is successful, the Cloud Icon will become blue, and a dialogue box will appear asking if you would like to create a customer – click 'Yes' to continue.

The EURO 46 V10 control panel is now successfully connected to the Insite UDL software.

## EN 50131 Terminology

EURO 46 V10 Language	EN50131 Language
Set	Set
Unset	Unset
Day or Unset Mode	Unset State (may be relevant to a specific partition)
HU (Hold Up)	Hold Up (HU)
Inhibit	Inhibit
Unused	Isolated
Bell / External Sounder / SAB	External Warning Device (self-powered is assumed)
Main Sounder / Speaker	Device combining internal warning device with audible indicator (using different tones and volumes)
Prox card, Tag, or Wireless Key Fob	Digital Key

## Access Levels

Level 1: Access by any person; for example the general public.

Level 2: User access by an operator; for example customers (systems users).

Level 3: User access by an engineer; for example an alarm company professional.

Level 4: User access by the manufacturer of the equipment.

**PLEASE NOTE:** Alarm, tamper and fault indications will automatically be cleared within 3 minutes. If a user has finished viewing the information they can terminate the display instantly by pressing the **YES** key.

## Compliance

As per EN 50131-1 the EURO 46 V10 is capable of supporting all conditions A,B and C: -

In Grades 1 & 2 I&HAS when an I&HAS or part thereof is in a set state:

A) access to the supervised premises or part thereof, via an entry/exit route, shall be prevented, or

B) opening the door to the entry/exit route shall initiate an entry procedure, or

C) indication of the set/unset status shall be provided.

In Grades 3 & 4 I&HAS when an I&HAS or part thereof is in a set state:

A) access to the supervised premises or part thereof, via an entry/exit route, shall be prevented, or

B) opening the door to the entry/exit route shall initiate an entry procedure.

## Warranty

This product is sold subject to our standard warranty conditions and is warranted against defects in workmanship for a period of two years. For further warranty information visit: [www.pyronix.com/warranty](http://www.pyronix.com/warranty).

The declaration of conformity and further compliance documentation may be consulted at: [www.pyronix.com/product-compliance.php](http://www.pyronix.com/product-compliance.php).

## Additional Device Manuals

Please scan the relevant QR code below to download the manual on a specific product. In order to download any of our manuals you will be required to sign up to the website. This can be done simply by going to [www.pyronix.co.uk/register](http://www.pyronix.co.uk/register) or scanning the QR code to the right.



### Wired Setting Devices

Contemporary Keypad



Surface and Flush Mount Keypad



Internal Proximity Reader



External Proximity Tag Reader



### Wireless Setting Devices

Wireless Arming Station



Wireless Keyfob



### Zone Expansion Modules

ZEM8



ZEM8+



ZEM8+PSU



Wireless ZEM



### Output Expansion Modules

OEM8R8T



OEM16R+PSU



### External Wired Sounders

Deltabell E and Plus



Deltabell X



Invincibell E



Invincibell X



## Customer Support



### Pyronix Training Academy Online

Connect to a whole host of exclusive training materials, including online weekly webinars and step-by-step training videos by joining the Pyronix Training Academy.

To start accessing an entire arsenal of training resources, simply email your full contact details and company name to [videot@pyronix.com](mailto:videot@pyronix.com) now. You will receive an email confirmation once your application has been approved.

**PLEASE NOTE:** It can take up to 48 hours to process your account.

Alternatively you can register online for one of our webinar sessions by going to the following address:

<http://bit.ly/2pWkknI>

([www.pyronix.co.uk/help-and-support/installers-distributors/courses-and-training](http://www.pyronix.co.uk/help-and-support/installers-distributors/courses-and-training))

### Pyronix Training Academy Training Videos

Watch easy step by step setup and training videos on a large range of our security solutions. Available for you to watch at your leisure, you can access them on-the-go to learn new skills, refresh your knowledge or even watch the latest videos on our newest releases or updates.

Email your full contact details and company name to [videot@pyronix.com](mailto:videot@pyronix.com) now and you can watch, learn and install whenever you want. You will receive an email confirmation once your application has been approved.

**PLEASE NOTE:** It can take up to 48 hours to process your account.

### Technical Support

If you are still experiencing issues with the installation, please call our UK technical support team.

**PLEASE NOTE:** In order to get your issue resolved quickly, please have the software revision of the panel ready to give to one of our engineers.

Alternatively if you do not require assistance straight away, you can always email the team who will reply to you as soon as possible.

Our office hours are: Monday to Friday 8:00 - 18:30.



0333 444 1280



[technical.support@pyronix.com](mailto:technical.support@pyronix.com)

